



7. ⑭ MOUNTING THE BRACKET TO ELECTRICAL BOX WITH SCREWS

8. ⑮ ATTACH THE FIXTURE WIRE TO THE HOUSE WIRE : GOUND WIRE TO GROUND WIRE ; WHITE (NEUTRAL) WIRE TO WHITE WIRE ; BLACK (HOT) WIRE TO BLACK WIRE

9. ⑯+⑰ FIX THE CANOPY TO CEILING BY INSIDE KNURLING RING

10. ⑱ PLACE BULBS (INCL.) INTO FIXTURE SOCKETS, DO NOT EXCEED MAXIMUM WATTAGE INDICATED

11. ⑲ PLACE CRYSTAL STRANDS ONTO FIXTURE , FOLLOW THE SEQUENCE ON THE DIAGRAM PROVIDED